Poultry Crate #540202



(at right) show a different size crate. However, installation is the same.



www.premier1supplies.com 800-282-6631

© Copyright 2019, Premier1Supplies. All rights reserved.



1. Insert panels into base. Match curve panels to curve of base.



2. Place top panel over side panels. Lining up pegs with holes (see inset above).



You should hear a "snap" when connected.



3. Press panels together (use a mallet if needed). 4. Make sure pegs and holes are connected.