

Heated Poultry Waterer

100 WATTS | 120 VOLTS | 3 GALLON

CAUTION - To provide continued protection against electrical shock:

1. Have a qualified electrician install a properly grounded receptacle outlet, acceptable for outdoor use and protected from snow and rain, immediately adjacent to the location where the bucket will be used.
2. Route the power cord to reduce animals pecking and walking on the cord.
3. Use the detachable power cord only, plugged directly into an outlet.
4. To ensure safety, please self-inspect the cord, plug and connection before using (or ask a certified electrician to do so).
5. Unplug bucket at receptacle outlet when not in use.
6. **CAUTION** - To ensure continued protection against electrical shock hazard, connect to properly grounded outlet.
7. Use with ground-fault interrupter in circuit.
8. This product is designed to de-ice water only. Do not use with chemicals, solvents or any flammable liquid.
9. Store indoors when not in use.



premier1supplies.com

800-282-6631

⚠ WARNING RISK OF ELECTRICAL SHOCK. Connect only to a branch circuit protected by a ground-fault circuit-interrupter (GFCI). Contact a qualified electrician if you cannot verify that the circuit is protected by a GFCI.

Parts of the bucket



Power Cord

Cord threads into place at base of the waterer.

Simply detach cord and cover prongs with rubber cap to store during warmer months.

To ensure safety, please self-inspect the plug and connection (or ask a certified electrician to do so.) Read more on the opposite side of this form.



Lid

Lid stays firmly attached to the bucket via bayonet lock closure.

Formed handle (right) is strong enough to support the weight of a full bucket for carrying or hanging.




Nipples

Side facing nipples with a drip catch base.

Some birds will need training to the nipples. Remove all other water sources. Hold the chicken and direct their head to the nipples. Guide the bird's beak and activate the nipple.

Hang or sit on a bucket



Hanging

The locking lid and formed handle are strong enough to support the waterer's full weight.

Using braided cord and a snap clip, attach to the waterer to hang.

Set the height at head high for the majority of the flock.

The braided cord #965410 and snap clips #965405 shown in photo are sold separately.



Bucket

Set the waterer (on a cinder block or 3.5 gallon bucket, sold separately, part #564500) so nipples are just above birds' head height. Birds should stretch up slightly to drink.