

Galvanized Cone Feeders

#540055, 540056, 540067

How to attach cone to base

1. Position cone base into two of the adjustment hinges. Lip of the cone should fit into their cutouts.
2. Twist the cone until the seam lines up with the empty hinge. Press into the base of the cone with your thumbs, while pushing on the side of the trough with your fingers. The seam will flex inward to catch under the hinge.
3. Adjust the rest of the base to the desired height.



800-282-6631

www.premier1supplies.com

© Copyright 2021, Premier1Supplies.
All rights reserved.

